

STIGA

ST 4262 P (2019)


18-2841-31



Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Body

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	5	112155000/0	Nut			
2	6	112154210/0	Nut			
3	1	1811-3074-01	Elbow link			
4	1	112293202/0	Nut			
5	1	118820274/0	Gear Bar			
6	4	122671651/0	Washer			
7	2	118820612/0	Armrest pads			
8	4	112691700/0	Screw			
9	4	2132110	Screw			
10	1	118821093/0	Belt Cover			
11	1	1811-3131-01	Belt Rod			
12	2	118820774/0	Screw			
13	1	9699-0090-02	Washer			
14	1	118820276/1	Chute Assembly			
15	1	1811-3078-01	Snow removal tool			
16	1	1811-3075-01	Nut			
17	1	1811-2994-01	Pad			
18	1	118820277/0	Hollow Worm			
19	1	1811-2995-01	Shaft			
20	1	1811-2997-01	Connect rod, under			
21	2	118820773/0	Pin			
22	1	1811-2996-01	Washer			
23	1	1811-2993-01	Aluminum bracket			
24	6	112530060/0	Spring Washer			
25	6	112727802/0	Screw			
26	3	1811-3077-01	Fixed block			
27	1	118820278/0	Belt			
28	4	112521330/0	Washer			
29	4	112582101/0	Grower			
30	4	118820881/0	Washer			
31	1	118821100/0	Gear connector bar Assy			
32	1	118821101/0	Pedrail bracket Assy			




Panel

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	1	118820613/1	Upper handle, Right			
2	1	118821096/0	Panel			
3	7	112154210/0	Nut			
4	2	122671651/0	Washer			
5	2	118820279/0	Cable Bracket			
6	4	112819100/0	Screw			
7	2	118820280/0	Clutch Cable			
8	2	112818900/0	Screw			
9	4	118820348/0	Pin	1.5X25		
10	1	1811-3025-01	Gear Handle Bar			
11	2	112295200/0	Nut			
12	2	118820615/0	Gear Handle			
13	1	1811-3027-01	Deflector Handle Lever			
14	2	1811-3070-01	Rubber pad			
15	1	118820283/0	Right Lever			
16	1	112523060/0	Washer			
17	1	118820877/0	Screw	M8x150		
18	1	112155000/0	Nut			
19	1	1811-3068-01	Stopper			
20	2	1811-3073-01	Locking pin			
21	1	118820284/0	Right Cam			
22	1	118820285/0	Left Cam			
23	1	1811-3067-01	Spring			
24	1	112819201/0	Screw			
25	2	118820363/0	Rivet			
26	2	118820776/0	Knob			
27	2	1811-3071-01	Spring			
28	1	118820286/0	Left Lever			
29	2	1811-3048-01	Bushing			
30	1	118820828/0	Deflector Control Cable			
31	1	118820878/0	Spring			
32	1	118820619/0	Rotating handle			
33	1	118820620/0	Rubber pad			
34	1	1811-3037-01	Lower fixing seat			
35	1	118820290/0	Flexible Shaft			
36	1	118820621/1	Upper handle, Left			
37	2	2132110	Screw			
38	1	118820291/0	Cover			
39	2	112154510/0	Nut			
40	2	118820003/0	Sleeve			




Transmission

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	2	9997-1025-16	Screw			
2	1	118820293/0	Handle, Lower			
3	2	118820294/0	Bracket			
4	2	112794900/0	Screw			
5	14	9997-0612-16	Screw			
6	2	118820295/0	Strut			
7	1	118820296/0	Cover			
8	1	112791400/0	Screw			
9	1	118820298/0	Sleeve			
10	1	118820094/0	Pulley Seat			
11	1	118820299/0	Wire			
12	1	118820300/0	Pulley			
13	3	112154510/0	Nut			
14	4	112793102/0	Screw			
15	1	118820301/0	Connecting Plate			
16	1	118820302/0	Engine Fixing Plate			
17	4	112691115/0	Screw			
18	4	112154210/0	Nut			
20	1	118820303/0	Belt			
21	1	118820101/0	Drive Pulley			
22	1	118820102/0	Pulley			
23	1	9699-0109-02	Washer			
24	1	118820775/0	Screw			
26	2	112791400/0	Screw			
27	1	1811-3012-01	Gear connector			
28	3	1811-3113-01	Plastic bushing			
29	1	118820308/0	Strut			
30	13	112791200/1	Screw			
31	2	118820309/0	Bearing Housing			
32	4	118820310/0	Ball Bearing			
33	1	112609800/0	Seeger			
34	1	118820312/0	Shift bearing			
35	1	118820634/0	Rubber wheel seat			
36	1	118820635/0	Rubber Wheel			
37	2	118820112/0	Sleeve			
38	1	118820315/0	Gear			
39	1	118820319/0	Hexagon Shaft			
40	1	118820322/0	Sprocket			
41	1	118820323/0	Spacer			
42	1	118820320/0	Transit shaft			
43	1	118820118/0	Chain Wheel			
44	1	118820119/0	Chain			
45	1	118821097/0	Complete Right Wheel	Tyre + Rim - Right		
46	2	118820636/0	Rimm			
47	4	112792611/0	Screw			
48	2	1811-3115-01	Bearing Housing			
49	6	112155000/0	Nut			
50	2	118820637/0	Ball Bearing			




Transmission

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
51	1	118820325/0	Spacer			
52	1	118820780/0	Drive gear			
53	2	118820353/0	Clip			
54	1	118820781/0	Axle			
55	2	118820328/0	Flat Key			
56	1	118820782/0	Flat Key			
57	2	118820783/0	Pin			
58	1	118820127/0	Shaft Sleeve			
59	1	112793701/0	Screw			
60	1	1811-3064-01	Tension pulley			
61	1	118820880/0	Tensioner			
62	1	112819105/0	Screw			
63	1	118820338/0	Bracket			
64	1	1811-3055-01	Bushing			
65	1	1811-3057-01	Tension pulley			
66	1	1811-3056-01	Pad			
67	1	118820334/0	Tensioner			
68	1	112521370/0	Washer			
69	1	112530150/0	Spring Washer			
70	1	118820336/0	Fixing Block			
71	1	1811-3118-01	Spring			
72	1	118820341/0	Support			
73	1	118820342/0	Spacer			
74	2	118820135/0	Screw			
75	1	112156603/0	Nut			
76	1	118820343/0	Brake Spring			
77	2	118820344/0	Rivet			
78	1	118820345/0	Brake block			
79	1	118820339/0	Pulley			
80	3	112791400/0	Screw			
81	2	1811-3116-01	Bearing Housing			
82	2	118820340/0	Ball Bearing			
83	1	118820347/0	Staffa			
84	1	118820348/0	Pin	1.5X25		
85	1	118820349/0	Spring			
86	1	1811-3125-01	Strut			
87	1	118820638/0	Bottom Plate			
88	1	118821098/0	Complete Left Wheel	Tyre + Rim - Left		
89	1	118821105/0	Friction disc Assy			
90	1	118821107/0	Big Tension plate Assy			
91	1	118821108/0	Small Tension plate Assy			
92	1	118821109/0	Pulley Seat Assy			




Housing

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	1	118820145/0	Housing Assy			
2	2	118820623/0	Skid Shoe			
3	2	118820624/0	Skid Shoe			
4	16	112154210/0	Nut			
5	6	9699-0090-02	Washer			
6	4	112818700/0	Screw			
7	9	112818690/0	Screw			
8	1	118820160/0	Plate			
9	2	118820639/0	Bearing cover			
10	2	118820147/0	Bearing			
11	6	112792611/0	Screw			
13	1	118820148/0	Auger-Rh			
14	2	112791500/0	Screw			
15	4	118820237/0	Sleeve			
20	2	1811-3080-01	Cotter Pin			
21	2	118820625/0	Shear Bolt			
30	4	112154510/0	Nut			
31	1	118820155/0	Auger-Lh			
32	4	118820156/0	Oil Cup			
33	1	118820627/0	Right Support			
34	4	112521330/0	Washer			
36	1	118820628/0	Left Support			
37	1	118820157/0	Ball Bearing			
38	1	1811-3109-01	Shaft sleeve			
39	1	118820158/0	Ball Bearing			
40	1	118820629/0	Seal Ring			
41	2	112674700/0	Screw			
42	1	118820630/1	Fan			
43	2	1811-3148-01	Screw			
44	1	118820250/0	Support			
45	1	118820159/0	Belt Pulley			
46	1	9699-0109-02	Washer			
47	1	9997-1025-16	Screw			
48	1	118820252/0	Key	6x20		
49	1	118820251/0	Round bottom			
50	1	1811-3134-01	Ball bearing			
51	1	118820818/0	Gear Box Assy			
52	1	118820876/0	Cylinder Pin	6x14		
53	1	118821102/0	Skid shoe Assy			
54	1	118821103/0	Support Assy			




Labels

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	1	114369167/0	Label			
2	1	114367495/1	Label			
3	1	114369171/0	Label			
4	1	114369146/0	Label			
6	1	114369761/0	Panel Safety Label			




Engine - Starter Assy, Tank

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	4	118550861/0	Screw			
2	1	118550628/0	Starter Assy			
3	1	118551306/0	Cover			
4	4	118551334/0	Screw			
5	1	118551319/0	Knob			
6	1	118551315/0	Remote Control Assy			
7	2	118550869/0	Screw			
8	1	118550399/0	Micro			
9	1	118551337/0	Screw			
10	1	118551313/0	Screw			
11	1	118550336/0	Nut			
12	1	118551194/0	Starter Cup			
13	1	118551169/0	Starter Cup			
14	1	118551327/0	Flywheel Ass.Y			
15	1	118551329/0	Coil Assy, Charge			
16	2	112674550/0	Screw			
17	2	112791500/0	Screw			
18	1	118550634/0	Coil Assy., Ignition			
19	1	2132510	Screw			
20	1	118551318/0	Knob			
21	3	118550816/0	Screw			
22	1	118551345/0	Cover			
23	1	118551312/0	Fuel switch assy			
25	1	118550806/0	Nut			
26	1	118551343/0	Fuel Hose			
27	3	118550816/0	Screw			
28	1	118551331/0	Support			
29	2	112674550/0	Screw			
30	1	118550640/0	Starter Motor 230V 50Hz			
32	1	118550796/0	Plate			
33	2	118550861/0	Screw			
34	1	118551170/0	Guard			
35	1	9400-0289-01	Spark Plug (Rn9Yc)			
36	2	118551336/0	Screw			
37	1	118551190/0	Gasket, Muffler			
38	1	118551321/0	Muffler Assy			
39	1	118550817/0	Muffler Guard			
40	5	118550816/0	Screw			
41	1	118551317/0	Tank Support			
42	4	118550816/0	Screw			
43	1	118551316/0	Tank Support			
44	1	118550500/0	Fuel Tank Hose Connection			
45	1	118551311/0	Fuel Tank			
46	4	118551334/0	Screw			
47	1	118550651/0	Fuel Filter			
48	1	118550650/0	Cap			
49	1	118551333/0	Rear Cover-Tank			
50	2	118550806/0	Nut			




Engine - Starter Assy, Tank

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
51	2	112293201/0	Nut			



Engine - Piston, Crankshaft

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
1	4	118551334/0	Screw			
2	1	118550784/0	Cover			
3	1	118551163/0	Gasket			
4	2	118550273/0	Valve Arm Set			
5	1	118550475/0	Valve Lifter			
6	2	118551166/0	Valve keeper			
7	2	118551167/0	Retainer			
8	2	118550896/0	Spring			
9	1	118551168/0	Gasket			
10	1	118551203/0	Valve Assy, Intake + Exhaust			
11	2	118550474/0	Push Rod			
12	2	118550623/0	Valve Lifter			
13	1	118550624/0	Camshaft assy			
14	4	118551200/0	Screw			
15	1	118551162/0	Cylinder Head			
16	1	118550783/0	Gasket			
17	2	118550460/0	Drain Plug bolt			
18	2	118550793/0	Washer , Drain Plug			
19	1	118550787/0	Speed Governor Assy			
20	2	118550280/0	Ball Bearing			
21	1	118550800/0	Crankshaft			
22	1	118550288/0	Woodruff Key			
23	1	118550519/0	Connecting Rod			
24	1	118550786/0	Piston Pin			
25	1	118551164/0	Piston			
26	2	118551201/0	Washer, Piston Pin			
27	1	118551165/0	Piston, Ring Set			
28	1	118550782/0	Crankcase Gasket			
29	1	118551292/0	Crankcase Cover			
30	1	118551338/0	Oil Seal			
31	6	118551199/0	Screw			
32	2	118551160/0	Oil Tank Cap			
33	1	118550792/0	Oil Seal			
34	1	118550795/0	Plate			
35	1	118550858/0	Washer			
36	1	118550459/0	Shaft, Governor Arm			
37	1	118551314/0	Arm Governor			
38	1	118550805/0	Screw			
39	1	112292102/0	Nut			
40	1	118550856/0	Cotter Pin			
41	2	118551335/0	Stud Bolt			
42	1	118551174/0	Carburetor Gasket			
43	1	118550484/0	Carburetor insulator			
44	1	118551173/0	Carburetor Gasket			
45	1	118551309/0	Carburetor			
46	1	118551184/0	Air Purge Pump			
47	1	118550886/0	Choke Lever			
48	1	118550482/0	Spacer			



Engine - Piston, Crankshaft

Ref.nr.	Qty	Item number	Description	Notes	From	Up to
49	1	118551320/0	Air Cleaner Assy			
50	2	118550806/0	Nut			
51	1	118550828/0	Starting Switch			
52	1	118550639/0	Switch Key			
53	1	118550794/0	Valve Assy			
54	1	118551342/0	Fuel Hose			
55	1	118550493/0	Governor Rod			
56	1	118550492/0	Spring			
57	1	118551291/0	Oil Filler Assy			
58	1	118551346/0	Cover			
59	1	118550816/0	Screw			
60	1	9942-0825-16	Screw			
61	1	118551339/0	Breather Pipe			
62	1	118551356/0	Engine Assembled			